



2025
New valve
EASY iQ

News coming soon!

Valve that elevates performance.

EASY iQ



PAST



Logix

FUTURE



EASY iQ

Substantial change



***Introduction of the new
valve protection COVER***

***Introduction of the new
CONTROLLER, with a new and
upgraded design, with new
valve programming features***

We have developed a kit to include the supply of the Controller + Cover, required to ensure the interchangeability of spare parts from the old LOGIX to the new EASY iQ

The new code is: NEA1015250 - Controller Changeout Kit from Logix to Easy-iQ

New technical details

DESCRIPTION	NOTES
Interchangeability of the old series product (Logix) with the new series called (EASY-iQ) Valve body remains the same	
Single programmer that makes it possible to continue carrying out the same functions:	- DELAYED Volume - IMMEDIATE Volume - Chrono (2 modes)
New programming, which makes it possible to limit access managed with Password:	1) Users 2) Installers 3) OEM
New programming, which makes it possible to limit access managed with Password:	- IT - DE - PL - EN - ES - FR - NL
Hardness selection in 3 units of measure:	- °f - °dH - ppm or mg/L

New technical details

DESCRIPTION	NOTES
New Backlit programmer with colour screens in accordance with the following standards:	Blue: Active / Programming / Connectivity Green: Regeneration Yellow: Error – Not Serious Red: Error – Very Serious
Improved buffer battery	
Pre-programmed settings, editable with simplified step-by-step programming of the customisable indices (regeneration cycle times, etc.). Always taking into account the limits due to the set safety level.	
Option to customise with your Company Service contact details	Contact Person Company Telephone No.

New technical details

DESCRIPTION	NOTES
Option to add SERVICE ALARM	Option to set between 1 and 48 months depending on one's needs.
The USB-C port is used for programming and loading or updating the software in the field. To enable constant improvement and upgrading of the valve's performance.	
New holiday mode, necessary to prevent bacterial proliferation during long periods of valve inactivity, when water therefore is not used.	

Softener - JUPITER

CODE	SOFTENER	MODEL	VERSION	"Old VALVE"	"New VALVE"
NEA1000001	JUPITER CAB	05	ATL - Minicab	Logix 255/740	Easy-iQ 255
NEA1000002	JUPITER CAB	10	ATL	Logix 255/740	Easy-iQ 255
NEA1000003	JUPITER CAB	15	ATL	Logix 255/740	Easy-iQ 255
NEA1000004	JUPITER CAB	30	ATL	Logix 255/740	Easy-iQ 255
NEA1000005	JUPITER CAB	05	AVL- Minicab	Logix 255/760	Easy-iQ 255
NEA1000006	JUPITER CAB	10	AVL	Logix 255/760	Easy-iQ 255
NEA1000007	JUPITER CAB	15	AVL	Logix 255/760	Easy-iQ 255
NEA1000008	JUPITER CAB	30	AVL	Logix 255/760	Easy-iQ 255
NEA1000009	JUPITER	10	ATL	Logix 255/740	Easy-iQ 255
NEA1000010	JUPITER	15	ATL	Logix 255/740	Easy-iQ 255
NEA1000011	JUPITER	30	ATL	Logix 255/740	Easy-iQ 255
NEA1000012	JUPITER	50	ATL	Logix 255/740	Easy-iQ 255
NEA1000013	JUPITER	70	ATL	Logix 255/740	Easy-iQ 255
NEA1000014	JUPITER	100	ATL	Logix 268/740	Performa 263/268 Easy-iQ
NEA1000015	JUPITER	120	ATL	Logix 268/740	Performa 263/268 Easy-iQ
NEA1000026	JUPITER	10	AVL	Logix 255/760	Easy-iQ 255
NEA1000027	JUPITER	15	AVL	Logix 255/760	Easy-iQ 255
NEA1000028	JUPITER	30	AVL	Logix 255/760	Easy-iQ 255
NEA1000029	JUPITER	50	AVL	Logix 255/760	Easy-iQ 255
NEA1000030	JUPITER	70	AVL	Logix 255/760	Easy-iQ 255
NEA1000031	JUPITER	100	AVL	Logix 268/760	Performa 263/268 Easy-iQ
NEA1000032	JUPITER	120	AVL	Logix 268/760	Easy-iQ 263/268

Softener - PEGASUS

CODE	SOFTENER	MODEL	VERSION	"Old VALVE"	"New VALVE"
NEA1000166	PEGASUS CAB	12	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000167	PEGASUS CAB	24	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000168	PEGASUS CAB	12	AVL	LOGIX 255/762	Easy-iQ 255
NEA1000169	PEGASUS CAB	24	AVL	LOGIX 255/762	Easy-iQ 255
NEA1000152	PEGASUS	12	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000153	PEGASUS	24	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000154	PEGASUS	36	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000155	PEGASUS	48	ATL	LOGIX 255/742	Easy-iQ 255
NEA1000156	PEGASUS	72	ATL	LOGIX 268/742	Performa 263/268 Easy-iQ
NEA1000157	PEGASUS	96	ATL	LOGIX 268/742	Performa 263/268 Easy-iQ
NEA1000158	PEGASUS	120	ATL	LOGIX 278/742	Performa CV 278 Easy-iQ
NEA1000159	PEGASUS	12	AVL	LOGIX 255/742	Easy-iQ 255
NEA1000160	PEGASUS	24	AVL	LOGIX 255/742	Easy-iQ 255
NEA1000161	PEGASUS	36	AVL	LOGIX 255/742	Easy-iQ 255
NEA1000162	PEGASUS	48	AVL	LOGIX 255/742	Easy-iQ 255
NEA1000163	PEGASUS	72	AVL	LOGIX 268/742	Performa 263/268 Easy-iQ
NEA1000164	PEGASUS	96	AVL	LOGIX 268/742	Performa 263/268 Easy-iQ
NEA1000165	PEGASUS	120	AVL	LOGIX 278/742	Performa CV 278 Easy-iQ

Media filter - MARS + VENUS

CODE	FILTER	MODEL	VERSION	"Old VALVE"	"New VALVE"
NEA1000075	MARS PRL	25	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000076	MARS PRL	50	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000077	MARS PRL	75	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000078	MARS PRL	100	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000079	MARS PRL	125	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000080	MARS PRL	150	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000086	MARS PRL	25	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000087	MARS PRL	50	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000088	MARS PRL	75	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000089	MARS PRL	100	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000090	MARS PRL	125	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000091	MARS PRL	150	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000097	VENUS	25	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000098	VENUS	50	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000099	VENUS	75	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000100	VENUS	100	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000101	VENUS	125	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000102	VENUS	150	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ

Media filter - SAND + VEGA

CODE	FILTER	MODEL	VERSION	"Old VALVE"	"New VALVE"
NEA1000057	SAND	25	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000058	SAND	50	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000059	SAND	75	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000060	SAND	100	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000061	SAND	125	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000062	SAND	150	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000066	SAND	25	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000067	SAND	50	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000068	SAND	75	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000069	SAND	100	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000070	SAND	125	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000071	SAND	150	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000119	VEGA	40	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000120	VEGA	55	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000121	VEGA	70	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000122	VEGA	110	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000123	VEGA	155	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000124	VEGA	170	ATL	LOGIX 263/740	Performa 263/268 Easy-iQ
NEA1000130	VEGA	40	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000131	VEGA	55	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000132	VEGA	70	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000133	VEGA	110	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000134	VEGA	155	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ
NEA1000135	VEGA	170	AVL	LOGIX 263/760	Performa 263/268 Easy-iQ



THANK YOU!